63602003GB.fm Page 21 Monday, May 29, 2006 11:32 AM

INSTRUCTIONS FOR USE

BEFORE USING THE APPLIANCE .....PAGE 22

SAFEGUARDING THE ENVIRONMENT .....PAGE 22

PRECAUTIONS AND GENERAL RECOMMENDATIONS .....PAGE 23

PRODUCT DESCRIPTION.....PAGE 24

REFRIGERATOR COMPARTMENT .....PAGE 25

FREEZER COMPARTMENT .....PAGE 28

GUIDE TO STORAGE AND THAWING OF FOOD .....PAGE 30

CARE AND MAINTENANCE.....PAGE 32

INSTALLATION.....PAGE 32

VACATION.....PAGE 35

TROUBLESHOOTING GUIDE / AFTER-SALES SERVICE .....PAGE 36

AFTER SALES SERVICE .....PAGE 37

ELECTRICAL CONNECTION.....PAGE 38

Downloaded from Fridge-Manual.com Manuals

BEFORE USING THE APPLIANCE

- Your new appliance is designed exclusively for domestic use

For best use of your appliance, carefully read the user's handbook which contains a description of the appliance and advice on how to store and preserve food.

Keep this handbook for future consultation.

1. After unpacking, make sure that the appliance is undamaged and that the door closes perfectly tight. Any damage must be reported to your dealer within 24 hours after delivery of the appliance.
2. Wait at least two hours before switching the appliance on in order to ensure the refrigerant circuit is fully efficient.
3. Installation of the appliance and electrical connections must be carried out by a qualified electrician, in accordance with the manufacturer's instructions and local safety regulations
4. Clean the inside of the appliance before using it.

SAFEGUARDING THE ENVIRONMENT

1. Packing

The packaging material is 100% recyclable and carries the recycling symbol. Follow local regulations for scrapping. Keep the packaging materials (plastic bags, polystyrene parts, etc.) out of reach of children, as they are potentially dangerous.

2. Scrapping

The appliance is manufactured using recyclable material.

This appliance is marked according to the European directive 2002/96/EC on Waste Electrical and Electronic Equipment (WEEE). By making sure this appliance is disposed of correctly, the user will help prevent potentially negative consequences for the environment and the health of persons.

The symbol on the appliance, or on the accompanying documents, indicates that this appliance should not be treated as domestic waste but must be taken to a suitable collection point for the recycling of electrical and electronic equipment.

Before scrapping, make the appliance unusable by cutting off the power cable and removing the doors and shelves so that children cannot easily climb inside the appliance.

Disposal must be carried out in accordance with local environmental regulations for waste disposal. Deliver the appliance immediately to an authorized dump; do not leave it unattended even for a few days, since it is potentially dangerous for children. For more information regarding the treatment, recovery and recycling of this appliance, contact your local office, the domestic waste collection service or the shop where you purchased the product.

Information:

This appliance does not contain CFCs (the refrigerant circuit contains R134a) or HFCs (the refrigerant circuit contains R600a) (see the rating plate inside the appliance).

Appliances with Isobutane (R600a): isobutane is a naturally occurring, low environmental impact gas. Caution is required, however, because isobutane is flammable. Therefore, ensure that the pipelines of the refrigerant circuit do not get damaged.

Declaration of conformity

- This appliance is designed to store food and is manufactured in conformity with European Directive 90/128/EEC, 02/72/EEC and Regulation (EC) No. 1935/2004

CE

- This product has been designed, manufactured and retailed in compliance with:

- the safety objectives of the Low Voltage Directive 73/23/EEC;
- the protection requirements of the “EMC” Directive 89/336/EEC, amended by Directive 93/68/EEC.

- The electrical safety of the appliance can only be guaranteed if the product is connected to an approved earth connection.



Downloaded from Fridge-Manual.com Manuals

PRECAUTIONS AND GENERAL RECOMMENDATIONS

- Use the refrigerator compartment only for the storage of fresh food and the freezer compartment only for the storage of frozen food, the freezing of fresh food, and to make ice cubes.
- During installation, make sure the appliance does not damage the power cable.
- Do not store glass containers with liquids in the freezer since they may burst.
- Do not eat ice cubes or ice lollies immediately after taking them out of the freezer since they may cause cold burns.
- Before servicing or cleaning the appliance, unplug it from the mains or disconnect the electrical power supply.
- Make sure that the appliance is not near a heat source.
- Do not store or use petrol, gas or flammable liquids in the vicinity of the appliance or other electrical appliances. The fumes can create a fire hazard or explosion.
- To ensure adequate ventilation, leave a space on both sides and above the appliance and follow the installation instructions.
- Keep the appliance ventilation openings free.
- All appliances equipped with an ice maker or water dispenser must be connected to a mains water supply that delivers potable water only (with water pressure between 1.7 and 8.1 bar (25 and 117 PSI)). Ice makers and/ or water dispensers not directly connected to a mains water supply must be filled with potable water only.
- Install and level the appliance on a floor strong enough to take its weight and in an area suitable for its size and use.
- For the water connection, use the pipe supplied with the new appliance and do not use that of the previous appliance.
- The appliance must be handled and installed by two or more persons.
- Place the appliance in a dry and well-ventilated place. The appliance is set for operation at specific ambient temperature ranges, according to the climatic class indicated on the data plate: The appliance may not work properly if it is left for a long period at a temperature above or below the indicated range.

Climatic Class	Amb. T. (°C)	Amb. T. (°F)
SN	From 10 to 32	From 50 to 90
N	From 16 to 32	From 61 to 90
ST	From 18 to 38	From 64 to 100
T	From 18 to 43	From 64 to 110

- Be careful not to damage the floors when you move the appliance (e.g. parquet flooring).
- Do not use mechanical, electric or chemical means other than those recommended by the Manufacturer to speed up the defrost process.
- Do not damage the refrigerator's refrigerant circuit pipes.
- Do not use or place electrical appliances inside the compartments if they are not of the type expressly authorised by the Manufacturer.
- This appliance is not designed for use by young children or the infirm without supervision.
- To avoid the risk of children being trapped and therefore suffocating, do not allow them to play or hide inside the appliance.
- Power cable modification or replacement must only be carried out by qualified personnel.
- Do not use single/multiple adapters or extension cables.
- It must be possible to disconnect the appliance from the mains by unplugging it or by means of a two-pole switch fitted upline of the socket.
- Ensure that the voltage indicated on the appliance data plate corresponds to the domestic supply voltage
- Do not swallow the contents (non-toxic) of the ice packs (if provided).
- The Manufacturer declines any liability if the above recommendations and precautions are not respected.

Downloaded from Fridge-Manual.com Manuals

PRODUCT DESCRIPTION



1. Fast freezing compartment
2. Ice cube tray
3. Ice compartment
4. Freezer thermostat
5. Freezer shelf
6. Fresh control compartment
7. Refrigerator thermostat
8. Refrigerator shelves
9. Crisper drawer
10. Freezer shelf
11. Egg tray
12. Top shelf
13. Spice rack (*)
14. Bottle rack
15. Bottle holder

(*) Optional

Note: The number of shelves and shape of accessories may vary, depending on the model.
All shelves, door trays and racks are removable.

DO NOT obstruct the fan intake area with food.
Attention: refrigerator/freezer accessories must not be washed in a dishwasher.

Downloaded from Fridge-Manual.com Manuals

REFRIGERATOR COMPARTMENT

This appliance is equipped with a No Frost system that does not require manual defrosting.
The appliance is also provided with a ventilated system, thanks to which the internal temperature is to all intents and purposes uniform.
Food can be arranged on any shelf inside the appliance. However, take care not to obstruct the air vents in order to allow air to circulate freely.
Optimal performance is obtained at temperatures between +18°C and +43°C.

SWITCHING ON THE APPLIANCE

- The appliance will switch on automatically when it is plugged in.
- The inside light switches on when the refrigerator door is opened

USING THE REFRIGERATOR

- Temperature Adjustment

For correct operation and optimum storage of food, adjust the temperature in the refrigerator and freezer compartments separately.

REFRIGERATOR THERMOSTAT

To adjust the temperature in the refrigerator compartment, turn the thermostat knob to the desired position.

Temperature	Type of use
Minimum 1-2	• Small amounts of food stored • The door is seldom opened
Medium 3-4	• Normal use
Maximum 5	• Large amount of food stored • The door is opened frequently



- After being switched on, the refrigerator needs approximately 2 hours to reach the correct temperature to store a typical volume of food in the refrigerator compartment.

Storing food in the refrigerator compartment
Position the food as shown in the figure.

A. Cooked food
B. Fish, meat
C. Fruit and vegetables
D. Bottles
E. Butter
F. Dairy products, cheese

To maintain the vitamins, aroma, substance and freshness of the food to be stored, it is advisable to wrap food in aluminium foil, cling film or place it in special freezer containers with lids. This will prevent odours from mixing.

NOTES:

- The space between the shelves and the rear wall must be unobstructed to allow circulation of air.
- Do not place food in direct contact with the rear wall of the refrigerator compartment.
- Do not place hot food in the refrigerator.
- Store liquids in closed containers.
- Storing vegetables with a high water content can result in condensation in the crisper drawer: this will not affect the correct operation of the appliance.
- Defrosting of the refrigerator compartment is completely automatic.
- The refrigerator can operate at ambient temperatures between +16°C and +43°C.

Downloaded from Fridge-Manual.com Manuals

FRESH CONTROL COMPARTMENT

This sliding compartment stays colder than the rest of the refrigerator compartment to keep daily foods fresh longer.

It is proper for keeping dairy products, cold cuts, sausage and meat.

If necessary, remove the fresh control compartment for cleaning.



DRAWER (depending on the model)

The drawer has four containers which can be used to store small food items.

For ease of use and optimum food storage, you can move the drawer to the right or left.

Furthermore, you can easily remove the drawer if necessary.

Note: close the drawer lids to prevent food from drying out and odours from mixing.



BOTTLE RACK (depending on the model)

Designed to hold bottles in the horizontal position.

The shelf beneath the bottle rack can be easily fitted by simply moving the rack to the right or left.

The bottle rack is easy to remove: simply pull the glass shelf outwards, slide the bottle rack to the right or left and remove it.

The bottle rack can be fitted on any glass shelf.

Note: make sure bottles are tightly closed to avoid spills.



Downloaded from Fridge-Manual.com Manuals

MOISTURE CONTROL (depending on the model)

The fruit and vegetables drawer is provided with a moisture control that allows you to control the necessary amount of air that goes into the drawer.

- We recommend to keep the control closed to preserve leafy vegetables and open to preserve fruit.



CRISPER DRAWER

Foods such as fruit and vegetables dehydrate when stored in direct contact with cold and dry air.

The crisper drawer keeps the temperature and humidity adequate for storage of fruits and vegetables, preserving their natural characteristics. Furthermore, this drawer is equipped with a filter that eliminates unpleasant odours.



TO REMOVE THE CRISPER DRAWER LID

First step: removing the crisper drawers

- The drawer slides out easily thanks to the wheels.
- Slide the drawer out as far as it comes, then lift the front end and pull the drawer out completely.

Second step: removing the central divider located between the drawers

- Tilt the divider to the left starting from the back.
- Remove the divider.

Third step: removing the crisper drawer lid

- Slide the crisper drawer lid outwards.
- Remove the lid.







Downloaded from Fridge-Manual.com Manuals

TO REPLACE THE CRISPER DRAWER LID

First step: replacing the crisper drawer lid
- Insert the back of the lid into the runners.
- Push the lid back into place.

Second step: replacing the crisper drawer divider
- Refit the divider in the specific slots located on the bottom of the compartment and crisper drawer wall as shown in the figure.

Third step: replacing the crisper drawers
- Replace the drawer on the wheels.
- Push it back into place.



FREEZER COMPARTMENT

After switching on the appliance, the freezer compartment takes approximately 3 hours to reach a suitable temperature for frozen food storage.
The freezer compartment, marked with the symbol ****, is used for storing frozen food and freezing fresh or cooked food. It also allows the making of ice cubes. The inner door of the freezer is especially suitable for storing ice cream or frozen food with a short storage time.
The maximum quantity of food which can be frozen in a 24 hour period is stated on the rating plate, inside the refrigerator compartment.



TEMPERATURE	LEVEL OF USE
Minimum 1-2	Minimum level: to be used when small amounts of food are stored in the freezer and the door is seldom opened.
Medium 3-4	Medium level: to be used in normal conditions
Maximum 5	Maximum level: to be used when large amounts of food are stored in the freezer and the door is opened frequently.

Downloaded from Fridge-Manual.com Manuals

ICE CUBES

- Take out the ice cube tray.
- Fill it with water to the indicated level.
- Replace the ice cube tray in its original position.
- When the ice cubes are ready, turn the knob to drop them into the ice bin. Do not fill the ice bin with water.





FAST FREEZING COMPARTMENT

- The fast freezing compartment enables you to freeze homemade and fresh foods more quickly.
- To open the compartment, lift the front lid and slide it backwards. To close the compartment, proceed in the same way.

Note: make sure that the front lid of the fast freezing compartment is closed before closing the door of the compartment.



Downloaded from Fridge-Manual.com Manuals

GUIDE TO STORAGE AND THAWING OF FOOD

PREPARING FRESH FOOD FOR FREEZING

It is important to wrap food so that no water, moisture, or vapour may penetrate; this avoids the transfer of odours and flavours throughout the refrigerator and allows better storage of frozen food. Use plastic containers with tight fitting lids, aluminium trays, aluminium foil, cling film and waterproof plastic wrappings.

Important:

- When shopping, leave frozen food purchases until last and transport the products in a thermally insulated cool bag.
- Place the items in the freezer compartment as soon as you get home.
- Avoid, or reduce temperature variations to the minimum.
- Respect the best-before date on the package.
- Always observe the storage information on the package.

SEALING

When sealing food in bags, squeeze out the air first.

Place labels on the inside of clear freezer bags; use self-adhesive labels on the outside of opaque ones.

Fasten the top of the bag with a string.

DEFROSTING

Here are some helpful tips.

Raw vegetables: do not thaw, put straight into boiling water and cook as usual.

Meat (large cuts): thaw in the refrigerator compartment without unwrapping. Before cooking, leave at room temperature for a couple of hours.

Meat (small cuts): thaw at room temperature or cook from frozen.

Fish: thaw in the refrigerator compartment without unwrapping or cook before fully thawed.

In the event of a power failure, the freezer compartment maintains the appropriate storage temperature for approximately 12 hours; during this time, we suggest you leave the door of the compartment closed. Do not refreeze partially thawed food.

Previously cooked food: reheat in the oven without removing it from its aluminium container.

Fruit: thaw in the refrigerator compartment

NOTE: Never place warm food in the freezer, instead allow it to cool at room temperature for 30 minutes, then wrap it and place in the freezer. Cooling hot foods before freezing saves energy and prolongs the life of the appliance.

Downloaded from Fridge-Manual.com Manuals

FOOD STORAGE CHART

Storage time will vary according to the quality of the food, the type of packaging or wrap used (moisture and vapour proof), and the storage temperature (which should be -18°C).

FOODSTUFF AND STORAGE TIME

Fruit	
Concentrated fruit juice	12 months
Fruit (in general)	8 to 12 months
Citrus fruit and fresh fruit juice	4 to 6 months
Vegetables	
Commercially frozen	8 months
Home frozen	8 to 12 months
Meat	
Sausages	4 weeks or less
Hamburgers	1 month
Beef, veal, lamb	2 to 3 months
Roasts	
Beef	6 to 12 months
Lamb and veal	6 to 12 months
Pork	4 to 8 months
Fresh sausages	1 to 2 months
Steaks and chops	
Beef	8 to 12 months
Lamb, veal, pork	2 to 4 months
Fish	
Cod, flounder, sole	6 months
Salmon	2 to 3 months
Mackerel, perch	2 to 3 months
Dressed fish (purchased)	3 months
Clams, oysters	3 to 4 months
Boiled fish, crabs	3 to 4 months
Raw prawns	12 months
Poultry	
Chicken or turkey (whole or parts)	12 months
Duck and goose	6 months
Offal	2 to 3 months
Poultry cooked in a sauce	6 months
Sliced meat (no sauce)	1 month
Stews	
Meat, poultry, and fish	2 to 3 months

DAIRY PRODUCTS

Butter	6 to 9 months
Margarine	12 months
Cheese	
Camembert, mozzarella, spreading cheese	3 months
Cream cheeses	do not freeze
Brie, Emmenthal, Swiss cheese, etc. (freezing may affect cheese texture)	6 to 8 months

Ice cream, fruit juices, milk	12 months

Eggs (Add sugar or salt to yolks or whole beaten eggs)	
Whole (beaten), whites, yolks	12 months

PASTRY AND BREAD

Leavened bread and rolls	3 months
Unbaked bread	1 month
Croissants	3 months
Cakes (not iced)	2 to 4 months
Cakes (iced) and biscuits	6 to 12 months
Fruit pies	12 months
Biscuit pastry	3 months
Pie pastry	4 to 6 months

Downloaded from Fridge-Manual.com Manuals

CARE AND MAINTENANCE

Before any cleaning or maintenance operation, unplug the appliance from the mains or disconnect the electrical power supply.
Periodically clean the refrigerator and freezer compartments with a sponge dampened in a solution of lukewarm water and special detergent for refrigerator interiors. Rinse and dry. Never use abrasive detergents. Never clean refrigerator parts with flammable fluids. The fumes can create a fire hazard or explosion.

- Clean with a damp cloth.
  Do not use abrasive products, scourers, stain-removers (e.g. acetone, trichloroethylene) or vinegar.

Dry with a soft cloth.

- Both refrigerator and freezer compartments are provided with an automatic defrosting function (no frost system).
- Do not use steam cleaners.
- Regularly clean the condenser (air vents at the rear of the appliance) with a vacuum cleaner or a brush (see figure).
- Ensure the seals are always perfectly clean.



INSTALLATION

Freestanding appliances (not built-in)

- Fit the spacers (if supplied) on the rear of the condenser positioned at the back of the appliance (see figure); alternatively, leave a space of at least 6 cm between the rear of the appliance and the wall.
- To optimize appliance efficiency, leave a 5 cm gap above the appliance and make sure that adjacent kitchen units are sufficiently distanced to allow air circulation.
- Ensure that the appliance is level, using the front adjustment feet if necessary.
- Regulations require that the appliance is earthed. The manufacturer declines all liability for injury to persons or animals and for damage to property resulting from failure to observe the above procedures and reminders.
- If the plug and socket are not of the same type, have the socket replaced by a qualified electrician.

Do not use extension leads or adapters.

Disconnecting the appliance

It must be possible to disconnect the appliance by unplugging it or by means of a double-pole switch isolating the socket.



Downloaded from Fridge-Manual.com Manuals

DOOR REVERSIBILITY

1. Unscrew the two screws which are fixing the middle hinge. Also remove the two big caps on the left. (FIG-1)



Figure-1

2. Dismantle the refrigerator and frezeer door from cabinet by pulling towards to you together with the middle hinge. (FIG-2)


Figure-2

3. Remove the kick plate by pulling forward.
Unscrew the bottom hinge fixing screws and remove it.
Unscrew the pin of hinge from Hole 1, rotate the bottom hinge 90° and screw the pin to Hole 2. (See Detail A) Then screw the hinge to bottom left side of refrigerator. (FIG-3)



Figure-3

4. Unscrew the screw fixing the top hinge cover and remove it.
Unscrew the two screws fixing the top hinge and remove it.
Insert the two big caps that are put in the user manuel bag to left side cap holes. (FIG-4)



Figure-4

5. Unscrew the screw fixing the top hinge pin.
Turn the pin by 180° then fix it to left side of the top hinge by screwing it. (FIG-5)



Figure-5

Downloaded from Fridge-Manual.com Manuals

6. Assemble the top hinge and hinge cover on the left side. (FIG-6)



Figure-6

7. Replace the top bushing and top bushing cap. (FIG-7) (You can use the bushing cap that is put in the user manuel bag)
Remove the bottom bushing and bottom stopper and assemble it to the left side. (FIG-7)

7.1 Remove the door handle caps. Unscrew the screws that are fixing the door handle. Assemble door handle to the right side by doing the reverse operation. (FIG-7/Detail-A)
(Only for New Emotion design)



Figure-7

8. Remove the top bushing and insert it into left hole. Remove the right door catcher and assemble the left door catcher (which is put in the user manual bag) to the left. (FIG-8)

8.1 Remove the door handle caps. Unscrew the screws that are fixing the door handle. Assemble door handle to the right side by doing the reverse operation. (FIG-8/Detail-A)
(only for New Emotion design)



Figure-8

9. Turn the middle hinge 180°. Assemble the freezer door and refrigerator door together with middle hinge (Reverse operation of item 2)
Fix the middle hinge by tighting the screws.
Finally,by using a knife cut left side of the kick plate and assemble it. (FIG-9)



Figure-9

Downloaded from Fridge-Manual.com Manuals

VACATION

Short vacation

There is no need to disconnect the refrigerator from the power supply if you will be away for less than three weeks. Use up perishable food, freeze other food.

Long vacation

Remove all the food if you are going away for three weeks or more. Unplug the refrigerator and clean it, rinse and dry.

Fix some wooden or plastic wedges to the upper part of both doors with adhesive tape and leave the doors open enough for air to circulate inside both compartments. This will prevent odour and mould from setting in.

Moving

- Take out all removable parts, wrap them well, and fix them together with adhesive tape so that they do not bang together or get lost.
- Close and fix both doors with adhesive tape and, again using adhesive tape, fix the power cable to the appliance.

Power failure

In the event of a power failure, call the local office of your electricity supply company and ask how long it is going to last.

1. For power failures lasting up to 24 hours, **keep both doors of the appliance closed**. This will allow the stored food to stay cold as long as possible.
2. Should the power failure last more than 24 hours, remove all frozen food and put it in a portable freezer with a key lock. If this type of freezer is not available and, likewise, no artificial ice packs are available, try to use up the food which is more easily perishable.
3. Bear in mind that a full freezer compartment will stay cold longer than a partially filled one.
4. Empty the ice bucket.

   Furthermore, a freezer full of frozen meat will stay cold longer than a freezer filled with pre-cooked food.

   If ice crystals are still visible on the food, it may be frozen again, although flavour and aroma may be affected. If food is found to be in a poor condition, it is best to throw it away.

Downloaded from Fridge-Manual.com Manuals

TROUBLESHOOTING GUIDE / AFTER-SALES SERVICE

Some noises are normal when the appliance is operating



Before contacting After-sales Service....

Performance problems often result from little things you can find and fix yourself without tools of any kind.

The appliance is not working

- Is the power cord damaged?
- Have you checked your home's fuses?

Water collects at the bottom of the refrigerator compartment:

- Is the defrost water drain blocked?

If there is water in the defrost pan:

- This is normal in hot, damp weather. The pan can even be half full. Make sure the refrigerator is level so that the water does not overflow.

If the edges of the refrigerator cabinet, which come in contact with the door seal, are warm to the touch:

- This is normal in hot weather and when the compressor is running.

If the light does not work:

- Have you checked your home's fuses?
- Is the power cable plugged into a live socket with the proper voltage?
- Has the light bulb burnt out?

In the case of burnt-out bulbs:

1. Always unplug the appliance from the mains.
- See the “Troubleshooting guide/After-sales Service” chapter”.

If the motor seems to run too much:

- Is the condenser free of dust and fluff?
- Are the doors properly closed?
- Are the door seals properly fitted?
- On hot days or if the room is warm, the motor naturally runs longer.

The appliance is excessively noisy:

- Is the appliance in contact with other furniture or objects?
- Are the pipes at the back touching or vibrating?

If the appliance door has been left open for a while or if large amounts of food have been stored, the motor will run longer in order to cool down the interior of the appliance.

Downloaded from Fridge-Manual.com Manuals

Remember
Motor running time depends on different things: number of door openings, amount of food stored, temperature of the room, setting of the temperature controls.
If, after performing the above checks, your appliance still does not work properly, contact the After-sales Service, explain the problem, specifying the model and appliance service number (stated on the data plate).

If the refrigerator temperature is too high
- Is the appliance installed near a heat source?
- Are the refrigerator controls correctly set?
- Has a large amount of food been added to the refrigerator or freezer?
- Check that the doors are not opened too often.
- Check that the doors close properly.
- Make sure that air flow vents inside the compartment are not blocked, as this prevents the circulation of cold air.

If there is moisture build-up
- Make sure that the food is properly packaged. Dry any dampness on food containers before placing them in the refrigerator.
- Check that the doors are not opened too often. When the door is opened, humidity from the room air enters the refrigerator. The more often the door is opened, the faster humidity builds up, especially when the room itself is very humid.
- If the room is very humid, it is normal for moisture to build up inside the refrigerator.
- It is normal for droplets of water to form on the back wall after the refrigerator self-defrosts.

If the doors do not open and close properly
- Check that food packages are not blocking the door.
- Check that the door trays, shelves and drawers are all positioned correctly.
- Check that the door seals are not dirty or sticky.
- Ensure the appliance is level.

Always disconnect the refrigerator from the power supply before replacing any light bulbs.

If the inside light is not working:
- Disconnect the appliance from the mains power supply.

Depending on the model
- Remove the bulb cover (depending on model)
- Unscrew or remove the bulb.
- Check the bulb and if necessary replace it.
- Some models are equipped with a special bulb, which does not unscrew. Pull towards the inside of the appliance. This bulb is available only from our After-sales Service. Replace using maximum 15W bulb.

AFTER SALES SERVICE

Before contacting After Sales Service:

1. See if you can solve the problem yourself (see "TROUBLESHOOTING GUIDE / AFTER-SALES SERVICE").
2. Switch the appliance on again to see if the problem has been solved. If it has not, disconnect the appliance from the power supply and wait for about an hour before switching on again.
3. If the problem persists after this course of action, contact After-sales Service.

Specify:
- the nature of the fault,
- the model,
- the Service number (the number after the word SERVICE on the rating plate inside the appliance),
- your full address,
- your telephone number and area code

Note:
The direction of door opening can be changed. If this operation is performed by After-sales Service it is not covered by the warranty.

SERVICE 0000 000 00000

Downloaded from Fridge-Manual.com Manuals

ELECTRICAL CONNECTION

1) For Great Britain only

Warning - this appliance must be earthed

Fuse replacement

If the mains lead of this appliance is fitted with a BS 1363A 13amp fused plug, to change a fuse in this type of plug use an A.S.T.A. approved fuse to BS 1362 type and proceed as follows:

1. Remove the fuse cover (**A**) and fuse (**B**).
2. Fit replacement 13A fuse into fuse cover.
3. Refit both into plug.

Important:

The fuse cover must be refitted when changing a fuse and if the fuse cover is lost the plug must not be used until a correct replacement is fitted.
Correct replacement are identified by the colour insert or the colour embossed in words on the base of the plug.
Replacement fuse covers are available from your local electrical store.



2) For the Republic of Ireland only

The information given in respect of Great Britain will frequently apply, but a third type of plug and socket is also used, the 2-pin, side earth type.

3) Socket outlet / plug (valid for both countries)

If the fitted plug is not suitable for your socket outlet, please contact Whirlpool Service for further instruction. Please do not attempt to change plug yourself. This procedure needs to be carried out by a qualified Whirlpool technician in compliance with the manufactures instructions and current standard safety regulations.

Downloaded from Fridge-Manual.com Manuals